

Tuna Freezer (-60°C Freezer)



58L



118L / 218L / 318L



458L

SAFETY SYSTEM

1. Perfect alarm system with buzzer sound and lamp flashing alarm functions
2. High and low temperature alarm, sensor fault alarm function are available
3. Multiple-protection function (Password protection, power-on delay, time between stops, refrigeration system operation protection during sensor failure)

TECHNICAL PARAMETERS

Model	BDF-60H58	BDF-60H118A	BDF-60H218	BDF-60H318	BDF-60H458
External Size(W*D*H) mm	600*680*920	900*750*920	1160*750*860	1530*750*860	2110*885*1095
Internal Size(W*D*H) mm	400*400*360	700*470*350	860*470*570	1330*470*570	1380*500*660
Capacity	58L	118L	218L	318L	458L
Temp. Range	-25°C ~ -60°C, adjustable				
Temp. Accuracy	0.1°C				
Control System & Display	Microprocessor control, LED display				
Audio & Visual Alarm	Height and low temperature alarm & Temperature sensor failure alarm				
Refrigeration Type	Optimized auto-cascade refrigerating system				
Refrigerant	Unique fluoride-free mixed refrigerant, CFC-Free				
Condenser & Evaporator	Optimized evaporation and condensation system, strong cooling and low energy consumption				
Construction	structure	150mm ultra-thick foam layer, dual-sealing design of door, for effective temperature protection.			
	Internal Material	304 Stainless Steel			
	External Material	Cold-rolled steel with anti-bacteria powder coating			
Consumption	300W	450W	550W	720W	780W
Power Supply	AC220V±10%, 50/60Hz				
Package Size(W*D*H) mm	690*760*1130	940*810*1050	1250*810*1000	1660*810*1000	2200*915*1210
Gross Weight	110kg	120kg	130kg	240kg	280kg