

RT-34

Using principle of hammer and collision between grinding chamber and jagged crushing liner, and adjust the output fineness by different pore size of replaceable filter screen, suitable for small scale production of every material.

Feature

- The fineness of powder can reach 5-60 mesh based on different characteristics.
- Safety design for example power supply is close when pulverizing lid is open.



Grinder

Specification

Model	Motor (HP)	Capacity (KG/HR)	Dimension (L*W*H mm)
RT-34	1	5~10	500*300*540

Filter

- Filter 1 hole size 12 mm.
- Filter 2 hole size 6.2 mm.
- Filter 3 hole size 2.5 mm.
- Filter 4 hole size 2.0 mm.
- Filter 5 hole size 0.4 mm.
- Filter hole size smaller than 0.4 mm. , 2 pcs

